

## Quick Start Guide

*Radar-Based Sensors for Detection and Measurement of Moving and Stationary Targets*

This guide is designed to help you set up and install the R-GAGE T30R sensor. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at [www.bannerengineering.com](http://www.bannerengineering.com). Search for p/n 217048 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.




**WARNING:**

- **Do not use this device for personnel protection**
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

## Overview


Figure 1. Sensing Range



Model	D0 (m)	D1 (m)	D2 (m)	D3 (m)
T30R-1515 Models	0	0.15	0.30	15
T30R-4545 Models	0	0.30	NA	10

## Features and Indicators

Figure 2. T30R Features



	LED	Color	Description
1	Power	Green	Power ON
2	Signal Strength	Red	Flashes in proportion to the signal strength
3	Output 1	Amber	Target is within the taught analog span or discrete output status
4	Output 2	Amber	Discrete output status
5	NO/NC	Amber	Normally open/normally closed status of discrete output Dual discrete models have two LEDs
6	n/a	n/a	Output Teach buttons

## Installation Instructions

### Install the Software

**Operating System**

Microsoft® Windows® operating system version 10 <sup>1</sup>

**Hard Drive Space**

500 MB

**Third-Party Software**

.NET

**USB Port**

Available USB port



**Important:** Administrative rights are required to install the Banner Radar Configuration software.

<sup>1</sup> Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.




1. Download the latest version of the software from [www.bannerengineering.com/us/en/products/sensors/software/radar-configuration.html](http://www.bannerengineering.com/us/en/products/sensors/software/radar-configuration.html).
2. Navigate to and open the downloaded file.
3. Click **Install** to begin the installation process.
4. Depending on your system settings, a popup window may appear prompting to allow Banner Radar Configuration to make changes to your computer. Click **Yes**.
5. Click **Close** to exit the installer.

## Mount the Device Using the Threaded Barrel

1. If your device came with a lock washer, place the lock washer on the barrel of the device.
2. Insert the barrel of the device through a hole or a bracket.
  - If desired and available, insert the device through an appropriately sized hole in the machine or equipment at the desired location.
  - If a bracket is needed, insert the device into the bracket.
3. Thread the mounting nut onto the barrel of the device, finger tight.
4. If using a bracket, mount the device and the bracket to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.
5. Check the device alignment, aiming it near parallel to, or down towards, the ground.
 

If aiming at a target, alignment and signal strength can be checked via the red Signal Strength LED or the Banner Radar Configuration Software.
6. Tighten the nut.
7. If using a bracket, tighten the mounting screws to secure the device and the bracket in the aligned position.


## Connect to the Sensor




- A = Pro Converter Cable (MQDC-506-USB)  
 B = Splitter (CSB-M1251FM1251M)  
 C = PC running Banner Radar Configuration software  
 D = T30R  
 E = Power Supply (PSW-24-1 or PSD-24-4)  
 F = Optional 5-Pin to 5-Pin Double-Ended Cordset (ex. MQDEC3-515SS)

## Wiring


Quick disconnect wiring diagrams are functionally identical.



\* Push-Pull output. User-configurable PNP/NPN setting.




\* Push-Pull output. User-configurable PNP/NPN setting.



\* Push-Pull output. User-configurable PNP/NPN setting.

**Key:**

- 1 = Brown
- 2 = White
- 3 = Blue
- 4 = Black
- 5 = Gray (Connect for use with remote input or Banner Radar Configuration software)



## Getting Started

Power up the sensor, and verify that the power LED is ON green.

### Connect to the Sensor

1. Connect the sensor to the splitter cable from the PRO-KIT.
2. Connect the external power and Pro Converter cable to the splitter cable.
3. Connect the Pro Converter cable to the PC.
4. Open the Banner Radar Configuration Software.
5. Go to **Sensor > Connect** on the **Navigation** toolbar.  
The **Connection** screen displays.
6. Select the correct **Sensor Model** and **Com Port** for the sensor.
7. Click **Connect**.  
The **Connection** screen closes and the sensor data displays.

## Specifications

**Range**

The sensor can detect an object at the following ranges, depending on the material of the target:  
 T30R-1515 models:  
 Detection Range: 0.15 m to 15 m (0.5 ft to 49.2 ft)  
 Measurement Range: 0.3 m to 15 m (1.0 ft to 49.2 ft)  
 T30R-4545 models:  
 Detection Range: 0.3 m to 10 m (1.0 ft to 32.8 ft)  
 Measurement Range: 0.3 m to 10 m (1.0 ft to 32.8 ft)

**Operating Principle**

Frequency modulated continuous-wave (FMCW) radar

**Operating Frequency**

122 GHz

**Supply Voltage (Vcc)**

Analog Voltage models: 12 V DC to 30 V DC

Analog Current and Dual Discrete models: 10 V DC to 30 V DC

Use only with a suitable Class 2 power supply (UL) or Limited Power Supply (CE)

**Power and Current Consumption, exclusive of load**

Power consumption: < 2.4 W

Current consumption: < 100 mA at 24 V DC

**Supply Protection Circuitry**

Protected against reverse polarity and transient overvoltages

**Linearity**<sup>2</sup>

< ± 4 mm

**Delay at Power-up**

< 300 ms

**Output Configuration**

Analog Outputs:

**Current models**

Discrete Output (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output  
 Analog output (White Wire): 4 mA to 20 mA

**Voltage models**

Discrete Output (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output  
 Analog output (White Wire): Configurable 0 V to 10 V or 0.5 V to 4.5 V

**Dual Discrete models**

Discrete Output 1 (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output  
 Discrete Output 2 (White Wire): Configurable PNP or NPN, or Pulse Frequency Modulated (PFM) output

**Repeatability**<sup>3</sup>

< 1 mm

**Maximum Output Power**

EIRP: 100 mW, 20 dBm

**Output Protection**

Protected against output short-circuit

**Remote Input**

Allowable Input Voltage Range: 0 to Vsupply

Active High (internal weak pull-down): High state > (Vsupply - 2.25 V) at 2 mA maximum

Active Low (internal weak pull-up): Low state < 2.25 V at 2 mA maximum

**Response Time**

Analog update rate: 2 ms

Discrete output response: 6 ms

Speeds given for fast mode. See the Instruction Manual for additional details.

**Indicators**

**Power LED:** Green, power on

**Signal Strength LED:**

Red Flash: weak signal

Red Solid: 4x threshold

**Output LEDs:** Amber, target within taught analog span/discrete output status

**NO/NC LED:** Amber, normally open/normally closed status of discrete output

See Figure 2 on p. 1

**Construction**

**Housing:** PBT

**Window:** COP

**Connections**

Integral M12 quick disconnect

150 mm (6 in) PUR cable with an M12 quick disconnect

Models with a quick disconnect require a mating cordset

**Vibration and Mechanical Shock**

All models meet MIL-STD-202F, Method 201A (Vibration: 10 Hz to 60 Hz maximum, 0.06 inch (1.52 mm) double amplitude, 10G acceleration) requirements. Method 213B conditions H&I.Shock: 75G with device operating; 100G for non-operation

**Operating Temperature**

-40 °C to +65 °C (-40 °F to +149 °F)

**Temperature Effect**

< ± 10 mm from -40 °C to +65 °C (-40 °F to +149 °F)

**Environmental Rating**

IEC IP67

<sup>2</sup> At ranges ≥ 0.5 m, from 0.3 m to 0.5 m, linearity ± 15 mm. Reference target with RCS = 1m²

<sup>3</sup> Repeatability < 10 mm at Excess Gain < 10x.

**Output Ratings**

Analog Outputs:  
 • **Current Output (T30R....-I.. models):** 1 kΩ maximum load resistance at 24 V; maximum load resistance =  $[(V_{cc} - 4.5)/0.02 \Omega]$   
 • **Voltage Output (T30R....-U.. models):** 2.5 kΩ minimum load resistance  
 Discrete Outputs:  
 • **Current rating = 50 mA maximum each**

Black wire specifications per configuration		
IO-Link Push/Pull	Output High	$\geq V_{supply} - 2.5 V$
	Output Low	$\leq 2.5V$
PNP	Output High	$\geq V_{supply} - 2.5 V$
	Output Low	$\leq 1V$ (loads $\leq 1 \text{ Meg}\Omega$ )
NPN	Output High	$\geq V_{supply} - 2.5 V$
	Output Low	$\leq 2.5 V$

White wire specifications per configuration		
PNP	Output High	$\geq V_{supply} - 2.5 V$
	Output Low	$\leq 2.5 V$ (loads $\leq 70 \text{ k}\Omega$ )
NPN	Output High	$\geq V_{supply} - 2.5 V$
	Output Low	$\leq 2.5 V$

**Certifications**



IND. CONT. EQ. E224071  
 UL Environmental Rating: Type 1



ETSI EN 305 550-1 V.1.2.1  
 ETSI EN 305 550-2 V.1.2.1  
 FCC/CFR-47 part 18  
 for others, contact Banner Engineering  
 Country of Origin: USA

**Beam Patterns**

The beam pattern of the radar sensor is dependent on the radar cross section (RCS) of the target.

The beam pattern graphs are guides for representative object detection capabilities based on different sized radar cross sections and corresponding example real world targets. Use the following charts as a starting point in application setup. Note that applications vary.

- Use the Beam Width versus Distance chart to understand where corresponding objects can be detected. Adjusting the signal strength threshold also affects the beam pattern when the target is constant.
- Use the Beam Width versus Degrees chart to help determine how much the target can tilt from 90 degrees while still maintaining detection.

Unless otherwise specified, the following beam patterns are shown with Signal Strength Threshold = 1.

**T30R-1515 Models**

Figure 3. Typical beam pattern, in meters, of T30R-1515 on representative targets





Figure 4. Typical beam pattern, in degrees, of T30R-1515 on representative targets



T30R-4545 Models

Figure 5. Typical beam pattern, in meters, of T30R-4545 on representative targets




Figure 6. Typical beam pattern, in degrees, of T30R-4545 on representative targets





Figure 7. Typical Beam pattern, in meters, of T30R-4545 with fixed target and various Signal Strength Thresholds



## Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

**THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.**

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com).

For patent information, see [www.bannerengineering.com/patents](http://www.bannerengineering.com/patents).

## Banner Engineering Corp. Software Copyright Notice

This software is protected by copyright, trade secret, and other intellectual property laws. You are only granted the right to use the software and only for the purposes described by Banner. Banner reserves all other rights in this software. For so long as you have obtained an authorized copy of this software directly from Banner, Banner grants you a limited, nonexclusive, nontransferable right and license to use this software.

You agree not to use, nor permit any third party to use, this software or content in a manner that violates any applicable law, regulation or terms of use under this Agreement. You agree that you will not reproduce, modify, copy, deconstruct, sell, trade or resell this software or make it available to any file-sharing or application hosting service.

**Disclaimer of Warranties.** Your use of this software is entirely at your own risk, except as described in this agreement. This software is provided "AS-IS." To the maximum extent permitted by applicable law, Banner, its affiliates, and its channel partners disclaim all warranties, expressed or implied, including any warranty that the software is fit for a particular purpose, title, merchantability, data loss, non-interference with or non-infringement of any intellectual property rights, or the accuracy, reliability, quality or content in or linked to the services. Banner and its affiliates and channel partners do not warrant that the services are secure, free from bugs, viruses, interruption, errors, theft or destruction. If the exclusions for implied warranties do not apply to you, any implied warranties are limited to 60 days from the date of first use of this software.

**Limitation of Liability and Indemnity.** Banner, its affiliates and channel partners are not liable for indirect, special, incidental, punitive or consequential damages, damages relating to corruption, security, loss or theft of data, viruses, spyware, loss of business, revenue, profits, or investment, or use of software or hardware that does not meet Banner minimum systems requirements. The above limitations apply even if Banner and its affiliates and channel partners have been advised of the possibility of such damages. This Agreement sets forth the entire liability of Banner, its affiliates and your exclusive remedy with respect to the software use. You agree to indemnify and hold Banner and its affiliates and channel partners harmless from any and all claims, liability and expenses, including reasonable attorney's fees and costs, arising out of your use of the Services or breach of this Agreement (collectively referred to as "Claims"). Banner reserves the right at its sole discretion and at its own expense, to assume the exclusive defense and control of any Claims. You agree to reasonably cooperate as requested by Banner in defense of any Claims.